

< **CURING GUIDE: COLOR PRIME DTF POWDER** >**MIRO 36 HEAT SETUP GUIDE**

Thank you for using the DTF Station Miro 36 with Color Prime DTF Powder. This short guide offers some simple tips to help you get the best results when curing your film.

*****Important Tip*****

When switching between **Standard Powder** and **Flex Powder**, **adjust the curing temperature** on your Miro 36 to ensure proper transfer curing and application.

FLEX POWDER TIP:

We recommend peeling the transfer film only **after** it has **COMPLETELY COOLED** following heat pressing.

< **HEAT TEMPERATURE SETUP** >

Here are the recommended temperature settings for each powder type:

POWDER TYPE	FRONT HEATING	MAIN HEATING
STANDARD	160°F	290°F
FLEX	160°F	Above 300°F

< **HOW TO ADJUST TEMPERATURE** >

Scan or Click the QR code
for a step-by-step calibration **video**.

Click here for support ▶
<https://bit.ly/miro36calibration>



< SUPPORT & HELP: We're Here for You >

Scan or **click the QR code** to connect with our **technical support team** on Discord.

Epson G6070 Customers

▼ Click here for support



<https://bit.ly/miro36support>

Prestige Customers

▼ Click here for support



<https://bit.ly/4lLkSlo>

We are always available to provide support should you have any questions.

Best Regards,
DTF Station